



CORPORATE OFFICE

51 S. 2nd Street, Hamilton, IL 62341
Ph. 217-847-3324 Toll Free 1-888-922-1293

Chico, CA Branch
530-893-0921
1-877-332-3268

Sioux City, IA Branch
712-255-3232
1-877-732-3268

Albion, MI Branch
517-629-2860
1-877-932-3268

Williamsport, PA Branch
570-980-9831
1-877-532-3268

High Springs, FL Branch
386-454-0237
1-877-832-3268

Fresno, CA Branch
559-495-0230
1-877-432-3268

Paris, TX Branch
903-784-6145
1-877-632-3268

Watertown, WI Branch
920-261-5363
1-877-232-3268

Chatham, VA Branch
434-432-8461
1-800-220-8325

Frankfort, KY Branch
502-848-0000
1-888-932-3268

DADANT M00410 6-FRAME POWER EXTRACTOR

*The Dadant newly re-designed 6-frame power extractor now has
an integral leg system and newly designed reel*



Easy to assemble.

Dimensions: 18" diameter, 40" high floor to top of tank, 16" floor to bottom of gate

All stainless steel and nylon construction – no paint to chip and peel – no plating to peel with age

Stainless steel tank all welded

Loading capacity – Six 6-1/4" or shallower frames radially each load with positive frame placement

Stainless steel fabricated reel

Easy-to-assemble legs simply attach with supplied bolts to leg brackets already in place on the extractor tank. This allows space for a 5-gallon pail to be placed under the honey gate.

Laser cut reel with spot welded reel clips for positive placement.

Radial extractors are the quickest, easiest, and most efficient way to extract honey from the comb. Uncapped combs are placed in the circular reel like spokes of a wheel with the frame top bars toward the outside of the reel. The reel spins, creating a centrifugal force. Because of the natural slant of the honeycomb cells, honey is thrown from both sides of the comb at once. No further handling of the frames is needed from starting to unloading time, freeing the operator for other work such as uncapping combs for the next load. With radial extractors, the outward pressure is against the top bar, not against the comb surface as in small, non-radial models, eliminating much of the breakage of the combs.

ASSEMBLY

1. Leg Attachment

- Remove legs and bolts from package.
- Lay tank on side on a soft surface (such as a towel) to prevent damage to the tank.
- Begin with inserting one leg into a bracket at a time and start both bolts in through the leg bracket and leg. Once the bolts are in place, tighten. Continue until all three legs are in place and set tank upright.




Easy-to-assemble legs

2. Motor Assembly

- Open the lid of the extractor and remove all packing holding the reel.
- Completely wash and dry the unit before use.
- Remove the power unit and fastener package from the separate carton.
- Remove the tape from the extractor drive shaft coupling, keeping the rubber bushing in position.
- Place the motor assembly on the stationary extractor lid aligning the bolt holes and the drive shaft coupling.
- Remove fasteners from package and assemble as shown in the diagram for all four bolt locations.

Check alignment of coupling and tighten mounting bolts.



Laser cut reel

NOTE: Securely anchor extractor using holes provided in leg feet.

OPERATION

- Frames of honey should have the cappings cut off both sides.
- Place 6-1/4" or smaller frames in reel frame clips. Top bar of frame should rest against outer ring of reel with bottom bar toward the center shaft.
- After loading is complete, close lid and turn on motor using electronic speed control.

NOTE: First year combs may require slower initial turning with gradual increases in speed. If you break combs, slow down and increase speed gradually.

Remember to keep the gate open with honey flowing out of the extractor while you are extracting so that you do not cause undo stress on the frames or the motor as the honey would build up in the extractor. You can shut the gate while you are changing pails or when the motor is turned off.



Laser cut reel with frame

MAINTENANCE

The top bearing is a sealed bearing and requires **no** lubrication or maintenance.

Clean extractor with soap and water (protecting the motor and speed control) and dry for storage between each use.

REPLACEMENT PARTS

04-39618	Replacement Tank - See 04-40703	03-50164	Replacement O-ring for plastic gate
04-40703	Replacement Tank (legs sold separately)	03-50670	Motor
04-40001	Stationary Lid	03-50671	Speed Control
04-40002	Movable Lid	03-50306	5/8" Nylon Bushing
04-40005	Bottom Basket Support	03-50665	Nylon Gate Assembly
04-40901	Radial Reel	03-50325	5/8" Shaft coupling (2 required)
04-40104	Reel Shaft	04-40606	Leg Set
04-40601	1/4" L-Bolt Assembly	03-50327	Rubber Cross only
03-50087	Bearing w/Snap Ring		