



CORPORATE OFFICE

51 S. 2nd Street, Hamilton, IL 62341
 Ph. 217-847-3324 Toll Free 1-888-922-1293

Chico, CA Branch
 530-893-0921
 1-877-332-3268

Sioux City, IA Branch
 712-255-3232
 1-877-732-3268

Albion, MI Branch
 517-629-2860
 1-877-932-3268

Williamsport, PA Branch
 570-980-9831
 1-877-532-3268

High Springs, FL Branch
 386-454-0237
 1-877-832-3268

Fresno, CA Branch
 559-495-0230
 1-877-432-3268

Paris, TX Branch
 903-784-6145
 1-877-632-3268

Watertown, WI Branch
 920-261-5363
 1-877-232-3268

Chatham, VA Branch
 434-432-8461
 1-800-220-8325

Frankfort, KY Branch
 502-848-0000
 1-888-932-3268

M00629 HEATED STIRRING SYSTEM 70 GALLON

DESCRIPTION


The Dadant Bottler Stirring and Blending System is designed to adapt easily to the Bottler/Melter. It is an excellent way to blend different types of honey or ingredients into your product and to heat the product quickly and uniformly to a precise temperature for easy bottling and extended shelf-life of honey before granulating occurs.

ASSEMBLY

After unpacking the unit, insert the assembly into your tank and bolt it in place with the nine L-bolts provided. Your assembly is now complete. A hex wrench is included if you wish to change the location of the paddles on the shaft.

OPERATION

To operate the Stirring & Blending System, fill Bottler outer tank with water. Plug heating element cord into an appropriate outlet and set thermostat at the desired temperature. Pour honey through movable lid into the honey chamber tank. Plug motor cord into a standard 110V grounded outlet and after the product temperatures reaches **approximately** 90 degrees, turn motor on to a low speed. **Do not stir honey at a fast speed** as this could cause aeration of the product.. When product has reached the desired temperatures, turn the motor off and then bottle your product.



Replacement Parts for M00629 Heated Stirring System

Part Number	Description	Part Number	Description
M00446-02	Motor & Speed Control Complete	03-50306	Nylon Bushing
03-50324	1/2" flex shaft coupling half	04-62001	Shaft 24"
03-50325	5/8" flex shaft coupling half	04-62002	Paddle Assembly
03-50327	Rubber spider	03-50078	Flange Bearing
04-44019	Half lid Assembly	446-02-1	Motor only
04-44040	Channel	446-02-2	Speed Control
04-62301	Stirring support		