



## CORPORATE OFFICE

51 S. 2nd Street, Hamilton, IL 62341  
Ph. 217-847-3324 Toll Free 1-888-922-1293

**Chico, CA Branch**  
530-893-0921  
1-877-332-3268

**Sioux City, IA Branch**  
712-255-3232  
1-877-732-3268

**Albion, MI Branch**  
517-629-2860  
1-877-932-3268

**Williamsport, PA Branch**  
570-980-9831  
1-877-532-3268

**High Springs, FL Branch**  
386-454-0237  
1-877-832-3268

**Fresno, CA Branch**  
559-495-0230  
1-877-432-3268

**Paris, TX Branch**  
903-784-6145  
1-877-632-3268

**Watertown, WI Branch**  
920-261-5363  
1-877-232-3268

**Chatham, VA Branch**  
434-432-8461  
1-800-220-8325

**Frankfort, KY Branch**  
502-848-0000  
1-888-932-3268

## M00617 HEATED STIRRING SYSTEM 25 GALLON 300# '96 MODEL

### DESCRIPTION


The Dadant Bottler Stirring and Blending System is designed to adapt easily to the 300# Bottler/Melter. It is an excellent way to blend different types of honey or ingredients into your product and to heat the product quickly and uniformly to a precise temperature for easy bottling and extended shelf-life of honey before granulating occurs.

### ASSEMBLY

After unpacking the unit, insert the assembly into your tank and bolt it in place with the nine L-bolts provided. Your assembly is now complete. A hex wrench is included if you wish to change the location of the paddles on the shaft.

### OPERATION

To operate the Stirring & Blending System, fill Bottler outer tank with water. Plug heating element cord into an appropriate outlet and set thermostat at the desired temperature. Pour honey through movable lid into the honey chamber tank. Plug motor cord into a standard 110V grounded outlet and after the product temperatures reaches **approximately** 90 degrees, turn motor on to a low speed. **Do not stir honey at a fast speed** as this could cause aeration of the product.. When product has reached the desired temperatures, turn the motor off and then bottle your product.



### Replacement Parts for M00617 Heated Stirring System

Part Number	Description	Part Number	Description
M00446-02	Motor & Speed Control Complete	03-50087	Snap ring bearing
04-40330	Stationary Lid	03-50324	1/2" flex shaft coupling half
04-40002	Movable Lid	03-50325	5/8" flex shaft coupling half
04-62301	Stirring support	03-50327	Rubber spider
03-50306	Nylon Bushing	446-02-1	Motor only
04-62001	Shaft 24"	446-02-2	Speed Control
04-62002	Paddle Assembly		