



## CORPORATE OFFICE

51 S. 2nd Street, Hamilton, IL 62341  
Ph. 217-847-3324 Toll Free 1-888-922-1293

**Chico, CA Branch**  
530-893-0921  
1-877-332-3268

**Sioux City, IA Branch**  
712-255-3232  
1-877-732-3268

**Albion, MI Branch**  
517-629-2860  
1-877-932-3268

**Williamsport, PA Branch**  
570-980-9831  
1-877-532-3268

**High Springs, FL Branch**  
386-454-0237  
1-877-832-3268

**Fresno, CA Branch**  
559-495-0230  
1-877-432-3268

**Paris, TX Branch**  
903-784-6145  
1-877-632-3268

**Watertown, WI Branch**  
920-261-5363  
1-877-232-3268

**Chatham, VA Branch**  
434-432-8461  
1-800-220-8325

**Frankfort, KY Branch**  
502-848-0000  
1-888-932-3268

## M00372 LIQUEFIER GRID & HEATER



**M00372 GRID**  
(FITS INSIDE THE M00370)

A heater and support accessory that allows the Dadant Cappings Tank M00370 to be used also as a liquefier. As a liquefier, the tank holds 3-60 pound containers of honey, round or square.



**M00370**  
**CAPPINGS TANK**

### ASSEMBLY

To convert your Dadant 36" Cappings Tank into a liquefier:

1. Insert the rubber stopper in the drain opening of the cappings tank.
2. Place the grid work in the tank
  - a. with the mesh up.
  - b. with the end of the grid having only one full-width bottom support toward the heating element end of the tank (this allows the grid to be removed without removing the heating element).
3. Remove the 1" brass plug from the cappings tank and insert the heater. (Sealing compound will be needed on the threads.)

Always submerge the heating element in water when it is operating. Operating an unsubmerged element can cause element damage.

## OPERATION

1. Place your containers of honey on the grid work.
2. Fill your tank with water to a desirable level. Hot water will reduce start-up time.
3. Plug in heater to a 120 volt outlet.
4. Turn heating element on--temperature can be regulated with the thermostat.
5. Monitor your honey temperature with a thermometer. (Refer to appropriate honey handling literature for information on proper heating of honey and the effects of overheating honey.)

### Replacement Parts for M00370 36" Cappings Tank


Part Number	Description
04-37002	Leg
03-50296	Caster with Brake
03-37003	Wooden Uncapping Cross Bar
03-50219	Tank Drain Assembly

### Replacement Parts for M00371 Cappings Baskets

Part Number	Description
04-37101	Basket Frame
04-37102	Basket Bottom

### Replacement Parts for M00372 Liquefier Grid & Heater

Part Number	Description
03-50218	Rubber Stopper
M00537	2000W Immersion Heater



**M00371  
CAPPINGS BASKETS**