

ASSEMBLY INSTRUCTIONS FOR 8-FRAME COMPLETE HIVE B52601


Note: Separate and identify parts before assembling. Nail sizes may vary due to availability.

Telescoping Cover

- 1 – Masonite
- 2 – Side Rails
- 2 – End Rails
- 1 – Metal Cover Pan
- 40 – $\frac{3}{4}$ " Nails
- 8 – $2\frac{1}{4}$ " Nails

1. Assemble Side and End Rails first and secure with two $2\frac{1}{4}$ " nails in each corner.
2. Set Masonite Panel in Frame (smooth side down) and secure with five $\frac{3}{4}$ " nails on each side.
3. Place Metal Cover over Masonite and Rails and secure with $\frac{3}{4}$ " nails on each side.


(See figure 1 for assembling Telescoping Cover)



Inner Cover


- 2 – End Cleats
- 2 – Side Cleats
- 1 – Masonite (with hole)
- 8 – $\frac{3}{4}$ " Nails

1. Assemble Cleats around Masonite Panel
 2. Secure each corner using two $\frac{3}{4}$ " nails
- (See figure 2 for assembling Inner Cover)*



Super/Hive Body

Use One 4D nail and six 7D nails in each corner.
(See figure 3 for assembling super/hive body)



Frame and Foundation Assembly

- 2 – End Bar
- 1 – Top Bar
- 1 – Bottom Bar
- 8 – 1¼" Nails
- 4 – ¾" Nails (to attach wedge)

1. Assemble Frame using two 1¼" nails in each corner.
2. Insert Foundation (sold separately) into slot in Bottom Bar.
3. Place wedge at top of foundation and nail to top bar.

(See figure 4 for assembling frames.)




Figure 4

Bottom Board

- 1 – Top Cleat
- 1 – Bottom Cleat
- 2 – Side Rails
- 1 – Bottom Boards
- 4 – 1¼" Nails
- 16 – 2¼" Nails
- 4 – ¾" Nails

1. Nail the side rails to the Bottom Boards using the 2¼" nails.
2. Nail the Top Cleat to the top of the Bottom Board using the 1¼" nails.
3. Nail the Bottom Cleat to the bottom of the Bottom Board using the ¾" nails.

(See figure 5 for assembling Bottom Board.)




Figure 5