

ASSEMBLY INSTRUCTIONS FOR 10-FRAME HOBBY KIT #2 M59601

Note: Separate and identify parts before assembling. Nail sizes may vary due to availability.

Telescoping Cover

- 1 – Masonite $\frac{1}{4}'' \times 17\frac{5}{16}'' \times 21\frac{3}{16}''$
- 2 – Side Rails $\frac{3}{4}'' \times 2\frac{1}{2}'' \times 21\frac{7}{8}''$
- 2 – End Rails $\frac{3}{4}'' \times 2\frac{1}{2}'' \times 18\frac{1}{8}''$
- 1 – Metal Cover Pan $\frac{1}{2}'' \times 18\frac{1}{4}'' \times 22''$
- 40 – $\frac{3}{4}''$ Nails
- 8 – $2\frac{1}{4}''$ Nails

1. Assemble Side and End Rails first and secure with two $2\frac{1}{4}''$ nails in each corner.
2. Set Masonite Panel in Frame (smooth side down) and secure with five $\frac{3}{4}''$ nails on each side.
3. Place Metal Cover over Masonite and Rails and secure with $\frac{3}{4}''$ nails on each side.

(See figure 1 for assembling Telescoping Cover)





Figure 2

Inner Cover


- 2 – End Cleats $\frac{3}{4}'' \times 1\frac{1}{4}'' \times 16\frac{1}{4}''$
- 2 – Side Cleats $\frac{3}{4}'' \times 1\frac{1}{4}'' \times 19\frac{7}{8}''$
- 1 – Masonite (with hole) $\frac{1}{8}'' \times 14\frac{11}{16}'' \times 18\frac{5}{16}''$
- 8 – $\frac{3}{4}''$ Nails

1. Assemble Cleats around Masonite Panel
 2. Secure each corner using two $\frac{3}{4}''$ nails
- (See figure 2 for assembling Inner Cover)

Super/Hive Body

Use One 4D nail and six 7D nails in each corner.
(See figure 3 for assembling super/hive body)

Figure 3



Frame and Foundation Assembly

- 2 – End Bar $\frac{3}{8}$ " x $1\frac{3}{8}$ " x $6\frac{1}{4}$ "
- 1 – Top Bar $\frac{3}{4}$ " x $1\frac{1}{16}$ " x 19"
- 1 – Bottom Bar $\frac{3}{8}$ " x $1\frac{1}{16}$ " x $17\frac{1}{16}$ "
- 1 - Plasticell Foundation
- 8 – $1\frac{1}{4}$ " Nails




Figure 4

1. Assemble Frame using two $1\frac{1}{4}$ " nails in each corner.
2. Insert Plasticell Foundation into slot in Bottom Bar.
3. Slightly bend Plasticell as you slide it into the GTB.

Bottom Board

- 1 – Top Cleat $\frac{3}{4}$ " x $\frac{3}{4}$ " x $14\frac{11}{16}$ "
- 1 – Bottom Cleat $\frac{3}{8}$ " x $\frac{3}{4}$ " x $14\frac{11}{16}$ "
- 2 – Side Rails $\frac{3}{4}$ " x $1\frac{15}{16}$ " x 22"
- 1 – Bottom Boards $\frac{3}{4}$ " x $15\frac{3}{16}$ " x 22"
- 4 – $1\frac{1}{4}$ " Nails
- 16 – $2\frac{1}{4}$ " Nails
- 4 – $\frac{3}{4}$ " Nails




Figure 5

1. Nail the side rails to the Bottom Boards using the $2\frac{1}{4}$ " nails.
2. Nail the Top Cleat to the top of the Bottom Board using the $1\frac{1}{4}$ " nails.
3. Nail the Bottom Cleat to the bottom of the Bottom Board using the $\frac{3}{4}$ " nails.

(See figure 5 for assembling Bottom Board.)

Assemble Smoker to Bellows using the four nuts provided.
(See figure 6.)




Figure 6